Accessories——One-Touch Fittings

One-touch fittings---threaded type




■ Product feature

- 1. Variable models can be widely used in every kind of pneumatic systems.
- 2. High circulation performance bear the same flow with the volume of the tube innerdiamater.
- 3. The nickel plated body is anti-corrosion and anti-pollution, which allows a broader application.
- 4. Metal fittings can be used in high temperature environment.

Specification

Operating pressure range	0~9kgf/cm²(0~0.9MPa)
Negative pressure	-750mmHg(10Torr)
Proof pressure	3MPa
Ambient and fluid temperature (°C)	0~150

Ordering code




Configuration table of tubing thread.

Product series	Thread connection I	Thread co	onnection II	
Product series	Thread connection 1 01	02	03	04
	01	•	•	
ВВ	02	•	•	•
DD	03		•	•
	04			•
	01	•	•	•
BD	02		•	•
טם	03			•
	04			
	01			
DII	02	•		
BU	03		•	
	04			•

Product series	Thread connection				
	01	02	03	04	
BZ	•	•	•	•	


Dimensions





Model\Item	RA	RB	LA	LB	С	H(Across flat)
BB0101	1/8"	1/8"	7.5	7.5	19.5	10
BB0102	1/4"	1/8"	10	7.5	22.5	14
BB0103	3/8"	1/8"	11	7.5	24	17
BB0202	1/4"	1/4"	10	10	25	14
BB0203	3/8"	1/4"	11	10	26.5	17
BB0204	1/2"	1/4"	14	10	30	21
BB0303	3/8"	3/8"	11	11	27.5	17
BB0304	1/2"	3/8"	14	11	31	21
BB0404	1/2"	1/2"	14	14	34	21


BD series





Model\Item	RA	RB	LA	LB	С	H(Across flat)
BD0102	1/4"	1/8"	10	8	14.5	14
BD0103	3/8"	1/8"	11	8	16	17
BD0104	1/2"	1/8"	14	8	19.5	21
BD0203	3/8"	1/4"	11	11	16	17
BD0204	1/2"	1/4"	14	11	19.5	21
BD0304	1/2"	3/8"	14	12	19.5	21


BU series





Model\Item	R	L	С	H(Across flat)
BU0101	1/8"	8	17	12
BU0202	1/4"	11	23	17
BU0303	3/8"	12	25	21
BU0404	1/2"	13.5	28	24

BZ series





Model\Item	R	L	С	H(Across flat)
BZ01	1/8"	7.5	11	10
BZ02	1/4"	10	14.5	14
BZ03	3/8"	11	16	17
BZ04	1/2"	14	19.5	21







AITTAE

One-touch fittings---threaded type



Product feature


- 1. Variable models can be widely used in every kind of pneumatic systems.
- 2. High circulation performance bear the same flow with the volume of the tube innerdiamater.
- 3. The nickel plated body is anti-corrosion and anti-pollution, which allows a broader application.
- $4. \ Metal\ fittings\ can\ be\ used\ in\ high\ temperature\ environments.$

Specification

Operating pressure range	0~9kgf/cm²(0~0.9MPa)
Negative pressure	-750mmHg(10Torr)
Proof pressure	3MPa
Ambient and fluid temperature (°C)	0~150

Note: The temperature resistance level of the tubing should be confirmed first when used in high temperature environments.

Ordering code



Note: When using the tubing $\Phi 8 \times \Phi 5.5$, the straight lock nut connector of BKC0806can be used.


09: Ф9mm

Configuration table of tubing and tubing thread

_			_		_			
Product series	Tubing outer	Tubing inner	Thread connection					
Froduct Series	diameter	diameter	M3	M5	01	02	03	04
	04	25	•	•	•			
	06	04			•	•	•	
08 10 12	08	05			•	•	•	
		06			•	•	•	
	10	65				•	•	•
	10	75				•	•	•
	40	08				•	•	•
	12	09				•	•	•

Dimensions

BKC series





Tubing diameter Φ [eter ΦD				C/A =====	H(Across	
Model\Item	Tubing outer diameter	Tubing inner diameter	R	L	С	K	flat)	flat)
BKC0425-M3			M3×0.5	3	17			8
BKC0425-M5	4	2.5	M5×0.8	3.5	17.5	5	8	8
BKC0425-01			1/8"	7.5	20.5			10
BKC0604-01			1/8"	7.5	22			10
BKC0604-02	6	4	1/4"	10	25.5	5.5	10	14
BKC0604-03			3/8"	11	27			17
BKC0805-01			1/8"	7.5				12
BKC0805-02		5	1/4"	10	27.5			14
BKC0805-03	8		3/8"	11	29	6.5	12	17
BKC0806-01	0		1/8"	7.5	24	0.5	12	12
BKC0806-02		5.5 or 6	1/4"	10	27.5			14
BKC0806-03			3/8"	11	29			17
BKC1065-02			1/4"	10	30			15
BKC1065-03		6.5	3/8"	11	31.5			17
BKC1065-04	10		1/2"	14	35.5	7.5	15	21
BKC1075-02	10		1/4"	10	30	1.5	13	15
BKC1075-03		7.5	3/8"	11	31.5			17
BKC1075-04			1/2"	14	35.5			21
BKC1208-02			1/4"	10	30			17
BKC1208-03		8	3/8"	11	31.5			17
BKC1208-04	12		1/2"	14	35.5	7.5	17	21
BKC1209-02	14		1/4"	10	30	1.5	17	17
BKC1209-03		9	3/8"	11	31.5			17
BKC1209-04			1/2"	14	35.5			21

Installation and application

- 1. Method of inserting or removal a tubing
- 1.1 Inserting a tubing

Place the locking cap over the tubing, and insert the tubing into the body, then tighten the locking cap. (As figure 1)

1.2 Removing a tubing

Loosen the locking cap first, then remove the tubing. (As figure 2) $\,$






Figure 1

Figure 2

2. Method of tightening the connector thread

Tighten the connector with a hex wrench, as shown below.

