TWG Series





Symbol









Product feature


- 1. JIS standard is implemented.
- 2. Widening the piston rod can effectively improve the impact resistance ability of the cylinder.
- The installation height is adjustable and several rod end modes can be selected. The cushion effect of the stopper cylinder with shock absorber is better.
- 4. Shockless stopper cylinder is attached with self-lock device, which can prevent the returning of rebound of rocker caused by bar objects.
- 5. Several series and specifications for stopper cylinders can be selected.

Specification


Bore size(mm)	32	40	50							
Fluid	Double acting type \ Single acting-pull type										
Action		Air(to be filtered by 40 μ m filter element)									
Operating	Double acting type		0.15~1.0MPa(23~145psi)								
pressure											
Proof pres	ssure	1.5MPa(215psi)									
Temperatu	ıre °C	-20~80									
Range of	stroke tolerance	+1.0 0									
Cushion ty	/pe	Bumper									
Lubrication	n	Non required									
Mounting	type	Flange(The mounting high can be changed)									
Stopper ty	rpe	Round rod, Flat	rod, Roller shock less stopp	er(with absorber)							
Port size	1		1/8"								


① PT thread, NPT thread and G thread are available. Add) Refer to Page 397~420 for details of sensor switch.

Ordering code



Lateral Load and Operation pressure








TW



■ Inner structure and material of major parts ■ Dimensions

TTG-K 21

No.	Item	Material
1	Back cover	Aluminum alloy
2	Bumper	TPU
3	Body	Aluminum alloy
4	Wear ring	Wear resistant material
5	Piston	Aluminum alloy
6	Magnet washer	Aluminum alloy
7	Packing	NBR
8	Flange	Aluminum alloy
9	Fixed nut	Carbon steel
10	Countersink screw	Carbon steel
11	Piston rod	Carbon steel with
11	r istori rou	20 μ m chrome plated
12	Fixed seat	Nodular cast iron
13	Lock pin	Cast steel
14	Rocker	Cast steel
15	Roller	Mild steel
16	Steel ball	Stainless steel
17	Obstruct block	Powder metallurgy
18	Cancel cap	Aluminum alloy
19	Shock absorber	
20	Lock ring	Powder metallurgy
21	Sliding bushing	Wear resistant material
22	Absorber fix and	POM
	adjust seat	1 - 11
23	Magnet	Plastic
24	Piston seal	NBR
25	Spring	Spring steel
26	O-ring	NBR
27	Silence	Sintered bronze particle




	7.15		, , ,	_	_	_		_		٠, ١
95	38		57	70	40	20	20			18
100	38		62	80	47	25		60		18
100	38		62	80	58	25		60	1	18
Н	НА	HB	K	KB	M		MA		Р	PA
37	6	15	9	50	M36×	1.5	38		1/8	9
44	6	16	9	60	M45×	1.5	38		1/8	12
54	6	16	9	60	M45×	15	38		1/8	10.
	95 100 100 H 37	95 38 100 38 100 38 H HA 37 6 44 6	95 38 100 38 100 38 1 H HA HE 37 6 15 44 6 16	95 38 57 100 38 62 100 38 62 H HA HB K 37 6 15 9 44 6 16 9	95 38 57 70 100 38 62 80 100 38 62 80 H HA HB K KB 37 6 15 9 50 44 6 16 9 60	95 38 57 70 40 100 38 62 80 47 100 38 62 80 58 H HA HB K KB M 37 6 15 9 50 M36× 44 6 16 9 60 M45×	95 38 57 70 40 20 100 38 62 80 47 25 100 38 62 80 58 25 H HA HB K KB M 37 6 15 9 50 M36×1.5 44 6 16 9 60 M45×1.5	95 38 57 70 40 20 100 38 62 80 47 25 100 38 62 80 58 25 H HA HB K KB M M 37 6 15 9 50 M36×1.5 38 44 6 16 9 60 M45×1.5 38	95 38 57 70 40 20 50 100 38 62 80 47 25 60 100 38 62 80 58 25 60 H HA HB K KB M MA 37 6 15 9 50 M36×1.5 38 44 6 16 9 60 M45×1.5 38	95 38 57 70 40 20 50 100 38 62 80 47 25 60 100 38 62 80 58 25 60 H HA HB K KB M MA P 37 6 15 9 50 M36×1.5 38 1/8' 44 6 16 9 60 M45×1.5 38 1/8'

Note: The type with magnet and the type without magnet have the same dimension. Note: The type with magnet and the type without magnet have the same dimension.

Flat rod(TWG-B, TTG-B) AB+Stroke φG $A + Stroke \times 2$ AC+Stroke 2-Sides 4-ФК (Thru.hole

Bore size\Item	Α	AB	A	C	В		C	D	Ε	G	GA
32	95	38	5	7	70		40	20	18.5	50	18
40	100	38	6	2	80	١.	47	25	22.5	60	18
50	100	38	6	2	80	1	58	25	22.5	60	18
Bore size\Item	Н	НА	HE	ß K		ΚB	M		MA	Р	PA
32	37	6	15	9		50	M3	6×1.5	38	1/8"	9
40	44	6	16	9		60	M4	5×1.5	38	1/8"	12
50	54	6	16	9		60	M4	5×1.5	38	1/8"	10


Shockless stopper(TWG-K(F), TTG-K(F))




		_							-				-		
Bore size\Item	Α	ļ	۱B	AC		ΑE		В	С	D		G		G	A
32	147.5	5 (0.5	57		1	ľ	70	40	20)	50)	18	}
40	172	1	10	62		1.5		80	47	2	5	60)	18	}
50	172	1	10	62		1.5		80	58	2	5	60)	18	}
Bore size\Item	Н	Н	A	НВ	k	(K	В	М		M	Ą	Р		PA
32	37	6		15	9)	50)	M36>	1.5	38		1/8	3"	9
40	44	6		16	9)	60)	M45>	·1.5	38		1/8	3"	12
50	54	6		16	9)	60)	M45>	1.5	38		1/8	3"	10
Bore size\Item	R		S		1			U		٧					
32	15		11	.5	28			24.5		4.5		7			
40	20		14		2	24		38	3	14					
50	20		14		2	4		38	3	14		٦.			

Note: The type with magnet and the type without magnet have the same dimension. The type with self-lock and the type without self-lock have the same dimension.

Roller(TWG-R, TTG-R)





Bore size\Item	Α	AB	AC	AE	В	С	D	Е	G	GA	Н
32	116	59	57	4	70	40	20	18.5	50	18	37
40	123	61	62	4	80	47	25	22.5	60	18	44
50	123	61	62	4	80	58	25	22.5	60	18	54
Bore size\Item	HA	НВ	K	KB	М		MA	Р	PA	R	RA
32	6	15	9	50	M36	×1.5	38	1/8"	9	20	8
4.0	_	40	Λ	60	M45	v1 E	38	1/8"	12	20	8
40	6	16	9	UU	10140	C.1 ^	J0	1/0	12	20	0

Note: The type with magnet and the type without magnet have the same dimension.




388


Airtae

TWG Series


Installation and application

1. Function & Operating Manual







- 2. Adjustment of Shock Absorber
- 2.1) The Shock Absorber had been adjusted before the cylinder finished.
- 2.2) The client can adjust it if necessary.
- 2.3) The steps are as following.
 - a. Loose the fixed screw.
 - b. Turn the Shock Absorber to adjust the cushion ability.
 - c. Fasten the fixed screw.



- 3. Multi-working position
- 3.1) If the body is fixed, just to adjust the scotch block, the working direction of the cylinder will be changed.
- $3.2) For TWG \, series, adjusting the position of flange \, can \, be \, changed \, the \, working \, height.$





- 4. Working Forbidden(Shock less stopper(K))
- 4.1) This function is used to cancel the stop action of the cylinder, and make the work piece pass easy.
- 4.2) The steps are as following.
 - a. Screw off the cancel screw from the flange.
 - b. Put the roller seat down.
 - c. Fasten the cancel screw in the screw hole on the fixed seat and the tail of the cancel screw should be inserted in the hole made on the roller seat.
- 5. How to use stopper function
- 5.1) When the shock absorber is impacted deeply, added impact energy must be avoided. The cylinder without shock absorber cann't be impacted by load, otherwise mechanical failure may be caused.
- 5.2) The maximum impact kinetic energy acting on the piston rod cann't exceed the allowable maximum values, otherwise mechanical failure may be caused.



6. Self-locking

Unusually, when the stopper cylinder is operating, work piece will be rebound as the effect of shocker absorber. In order to keep the work piece steady, we have developed this self-locking device.







TW